Product Description

FX Super Easy Concrete is made for DIY home-renovators. NO PROFESSIONAL REQUIRED! It is a superior, acrylic paint finish. Its depth and movement mimic classic Venetian Plaster to give a subtle, undulated colour-effect. The coating dries to a matte finish; can be trowel-polished to a satin finish; or sandpapered to a high sheen, creating a perfect backdrop for both classic and industrial design concepts.

This is a specialty product. The end-result may differ from the FX Standard or images on social media depending on applicator technique and expertise. Always test the product before commencing a project.

Features

Water-based Attractive finishes Many varying effects Tintable **Benefits**

Ease of application Easy spreading Easy clean-up

Uses

FX Super Easy Concrete can be used on most interior surfaces such as plaster, plasterboard and cement render or sound, previously painted surfaces.

Surface Preparation

All surfaces must be thoroughly cleaned and free of dirt, dust, grease, loose or flaking paint, and loose surface plaster. Efflorescence or mould on masonry or concrete surfaces must be treated. Flatten gloss surfaces by thoroughly sanding and wipe clean with a damp cloth. Then apply FX Max Superprep Undercoat as required. For best results, surfaces should be well prepared and smooth.

Application

Stir contents thoroughly before and during use with a broad, flat stirrer using an upward action, or ideally use a power-driven mixing paddle.

Trowel: Requires 3 coats applied with a brush or roller and a stainless-steel stucco trowel. Different sized trowels give different finishes. STEP1: Brush or roll product onto the pre-prepared surface then while the product is still wet, move a trowel smoothly and evenly over the surface to create a pattern. The trowel is held at an approximate 45-degree angle to the surface during application. Allow to dry for 3-6 hours. STEP 2 & 3: Repeat the application process as STEP 1 for Step 2 & 3 with added pressure applied to the trowel during trowelling to create a distinctly stucco look and a higher sheen. Allow to dry for 3-6 hours between each application. Leave the finish as completed or polish with an ultra-fine sanding block.

Clear Coating: Generally, not required. For hardwearing areas or to achieve better resistance, apply a coating of clear FX Wicked Wax® by trowel.

Approximate Spreading Rate: 8-10 square metres per litre, depending on application technique and surface roughness.

Approximate Film Thickness per coat: Wet: 200 Microns; Dry: 100 Microns.

Requires: 2–3 coats. **Thinner:** Not required.

Tinting: Refer to colour chart for tinting specifications.

Method: Stainless steel stucco trowel.

Drying Times (at 25 °C): Touch: 2 Hours; Recoat: 6 Hours.

Note: Do not apply paint if the air temperature or substrate temperature is below 10 $^{\circ}$ C or above 35 $^{\circ}$ C.

The temperature should not fall below 10 °C during the drying process.

Clean-up: Water. Safety: Dust Mask. Gloss Level: N/A

Safety and Environmental Care

First Aid

Keep out of reach of children. Provide adequate ventilation. Avoid contact with skin and eyes. If eyes or skin become irritated, flush / clean with water then seek medical attention. If swallowed DO NOT INDUCE VOMITING and seek medical attention.

Personal Protection

Wear eye protection and dust mask when spraying, as splashes may cause eye irritation and inhalation of spray mist may cause respiratory irritation. Wear appropriate safety breathing apparatus when sanding.

Asbestos cement sheeting

Do not disturb, sand or scrub, and avoid any peripheral dust. If you do not have professional expertise in the handling/removal of asbestos sheeting, use a licensed asbestos removalist.

Refer to product labels, current FX Australia Safety Data Sheets or call FX Australia for detailed information.

Clean-up

Slippery when spilled • Restrict access to area until clean-up is completed • When cleaning up spills, use personal protection equipment • Stop leak if safe to do so and contain spill with absorbent material such as sand, vermiculite, or other inert material. Prevent spill from entering waterways • Collect and dispose of spilled material according to local regulations • Wash away remnants with liberal amounts of cold water.

Storage

Store in a cool, dry, well-ventilated place out of direct sunlight • Store away from strong acids and moisture • Keep containers closed at all times and check regularly for spills.

Disposa

Refer to State/Territory Land Waste Management Authority: most authorities permit disposal at approved land waste sites.

Important Notes:

Always read the Product Information Sheet and label to ensure this product is appropriate for your project. If unsure contact FX Australia direct. Always test the product before commencing a project.

FX Super Easy Concrete is porous. It is highly recommended a topcoat of FX Wicked Wax (INTERIOR ONLY) is applied as a protective coating to ensure the finish is durable.

Respect the drying times before applying the wax.

Ensure the entire process from preparation coat to finish coat incorporates all stages and only uses the recommended FX Products (the 'FX System'). DO NOT insert non-FX branded products into an FX System without the written approval of FX. Failure to follow FX recommendations or application steps may result in product failure and may void any warranty.

For any uncommon substrates, unusual angles or structures call FX direct to ensure the proposed FX product and system are appropriate.

The information in this Product Information Sheet is supplied in good faith. Other than as required under the Australian Consumer Law and any other relevant and applicable New South Wales and/or Australian Commonwealth legislation, FX provides no warranties or representations in supplying this product.

Date of Reissue: April 2023

